

### Table of Contents

SAFETY INSTRUCTIONS	PAGE 4
PREPARATION	PAGE 5
HARDWARE LIST	PAGE 6
HARDWARE ILLUSTRATION	PAGE 8
PART / LIST ILLUSTRATION	PAGE 14
ASSEMBLY INSTRUCTIONS	PAGE 20
EXPLODED VIEW	PAGE 37
CONTACT PAGE	PAGE 38

### Important Safety Instructions

Before beginning any fitness program, you should obtain a complete physical examination from your physician.

Il est conseille de subir un examen medical complet avant d'entreprendre tout programme d'exercise. Si vous avez des etourdissements ou des faiblesses, arretez les exercices immediatement.

Antes de comenzar cualquier programma de ejercicios, deberias tener un examen fisico con su doctor.

#### When using exercise equipment, you should always take basic precautions, including the following:

- Read all instructions before using the S2IOT. These instructions are written to ensure your safety and to protect the unit.
- O Do not remove any safety labels from the machine.
- O Do not allow children on or near the equipment.
- Use the equipment only for its intended purpose as described in this guide. Do not use accessory attachments that are not recommended by the manufacturer. Such attachments might cause injuries.
- Wear proper exercise clothing and shoes for your workout, no loose clothing.
- Keep hands, limbs, loose clothing, and long hair well out of the way of all moving parts.
- Use care when getting on or off the unit.
- O Do not overexert yourself or work to exhaustion.
- O If you feel any pain or abnormal symptoms, stop your workout immediately and consult your physician.
- Never operate unit when it has been dropped or damaged. Return the equipment to a service center for examination and repair.
- Never drop or insert objects into any opening in the equipment.
- Always check the unit and its cables before each use. Make sure that all fasteners and cables are secure and in good working condition.
- Do not use the equipment outdoors or near water.

#### **Personal Safety During Assembly**

- Before beginning assembly, please take the time to read the instructions thoroughly.
- O Read each step in the assembly instructions and follow the steps in sequence. Do not skip ahead. If you skip ahead, you may learn later that you have to disassemble components and that you may have damaged the equipment.
- Assemble and operate the **S2IOT** on a solid, level surface. Locate the unit a few feet from the walls or furniture to provide easy access.

The **S2IOT** is designed for your enjoyment. By following these precautions and using common sense, you will have many safe and pleasurable hours of healthful exercise with your Body-Solid Inner/Out Thigh Machine.

After assembly, you should check all functions to ensure correct operation. If you experience problems, first recheck the assembly instructions to locate any possible errors made during assembly. If you are unable to correct the problem, call the dealer from whom you purchased the machine or call **1-800-556-3113** for the dealer nearest you.

#### **Obtaining Service**

Please use this Owner's Manual to make sure that all parts have been included in your shipment. When ordering parts, you must use the part number and description from this Owner's Manual. Use only Body-Solid replacement parts when servicing this machine. Failure to do so will void your warranty and could result in personal injury.

For information about product operation or service, check out the official Body-Solid website at www.bodysolid.com or contact an authorized Body-Solid dealer or a Body-Solid factory-authorized service company or contact Body-Solid customer service at one of the following:

Toll Free:	1-800-556-3113
Phone:	1-708-427-3555
Fax:	1-708-427-3556
Hours:	M-F 8:30-5:00 CST
E-Mail:	service@bodysolid.com

Or write to: Body-Solid, Inc. Service Department 1900 S. Des Plaines Ave. Forest Park, IL 60130 USA

Retain this Owner's Manual for future reference. If you need to order replacement parts please be prepared to provide the following information when contacting us so that we can assist you better.

- **1. Model Number**
- 2. Place of Purchase
- 3. Serial Number (S/N)
- 4. Part # and Description

### Preparation

Thank you for purchasing the **S2IOT**. This bench is part of the Body-Solid line of quality strength training machines, which lets you target specific muscle groups to achieve better muscle tone and overall body conditioning. To maximize your use of the equipment please study this Owner's Manual thoroughly.

#### **Required Tools**

The basic tools that you must obtain before assembling the **S2IOT** include but are not limited to:

- Metric Allen Key Set
- O Standard Allen Key Set
- O Standard Wrench Set
- O Metric Wrench Set
- Adjustable Wrench
- O Screwdriver (standard and/or phillips)

#### Installation Requirements

Follow these installation requirements wher the **S2IOT**:

Set up the **S2IOT** on a solid, flat surface. A surface under the machine helps keep it lev level machine has fewer malfunctions.

Provide ample space around the machine.  $\Box_{PC} \parallel$  space around the machine allows for easier access.

Insert all bolts in the same direction. For aesthetic purposes, insert all bolts in the same direction unless specified (in text or illustrations) to do otherwise.

Leave room for adjustments. Tighten fasteners such as bolts, nuts, and screws so the unit is stable, but leave room for adjustments. Do not fully tighten fasteners until instructed in the assembly steps to do so.

Fill out and mail the warranty card.

#### Assembly Tips

Read all "Notes" on each page before beginning each step.

While you may be able to assemble the **S2IOT** using the illustrations only, important safety notes and other tips are included in the text.

Some pieces may have extra holes that you will not use. Use only those holes indicated in the instructions and illustrations.

> hile 5 leave

; your :n


u can't n do

sult in

ments

steps.

NOTE: With so many assembled parts proper



Your S/N# can be found here


Body-Solid continually seeks ways to improve the performance, specifications and product manuals in order to ensure that only superior products are released from our factories. Please take the time to carefully read through this manual thoroughly. Instructions contained in this document are not intended to cover all details or variations possible with Body-Solid equipment, or to cover every contingency that may be met in conjunction with installation, operation, maintenance or troubleshooting of the equipment. Even though we have prepared this manual with extreme care, neither the publisher nor the author can accept responsibility for any errors in, or omission from, the information given. Should additional information be required, or should situations arise that are not covered by this manual, the matter should be directed to your local Body-Solid representative, or the Service Department at Body-Solid Inc. in Forest Park, Illinois.


### S2IOT Hardware List


Part#	Size	Description	Quantity
1	M10X105mm	HEX HEAD BOLT	2 PCS.
2	M10X35mm	HEX HEAD BOLT	1 PCS.
3	M10X45mm	HEX HEAD BOLT	3 PCS.
4	M10X50mm	HEX HEAD BOLT	6 PCS.
5	M10X75mm	HEX HEAD BOLT	5 PCS.
6	M10X80mm	HEX HEAD BOLT	6 PCS.
7	M12X35mm	HEX HEAD BOLT	4 PCS.
8	M10X25mm	HEX HEAD BOLT	5 PCS.
9	M4X15mm	SOCKET HEAD CAP SCREW	1 PCS.
10	M8X20mm	SOCKET HEAD CAP SCREW	1 PCS.
11	M4X8mm	SET SCREW	1 PCS.
12	M8X8mm	SET SCREW	4 PCS.
13	M6X16mm	PHILLIPS HEAD SCREW	3 PCS.
14	M4X10mm	FLAT PHILLIPS HEAD SCREW	4 PCS.
15	M5X16mm	FLAT PHILLIPS HEAD SCREW	2 PCS.
16	M10X50mm	BUTTON HEAD CAP SCREW	1 PCS.
17	M6X40mm	BUTTON HEAD CAP SCREW	1 PCS.
18	M8X25mm	BUTTON HEAD CAP SCREW	4 PCS.
19	10-32X3.2mm	SET SCREW	8 PCS.
20	M10X25mm	FLAT HEAD CAP SCREW	2 PCS.
21	3/8"X2.0"	SOCKET HEAD CAP SCREW	1 PCS.
40	1/2"-13	HEX NUT	1 PCS.
41	M10	NYLON LOCK NUT	18 PCS.
42	M12	NYLON LOCK NUT	4 PCS.
43	M6	NYLON LOCK NUT	1 PCS.


### S2IOT Hardware List


Part#	Size	Description	Quantity
44	M8	NYLON LOCK NUT	4 PCS.
51	Ф10mm	SPRING WASHER	7 PCS.
52	Ф11ХФ20Х2mm	FLAT WASHER	41 PCS.
53	Ф13ХФ24Х2.5mm	FLAT WASHER	8 PCS.
54	Ф6.6ХФ12Х1.6mm	FLAT WASHER	4 PCS.
55	Ф9ХФ16Х1.6mm	FLAT WASHER	8 PCS.
57	1/2"	SPRING WASHER	1 PCS.
58	3/8"	SPRING WASHER	1 PCS.















PART A -- FRAME A, 1 PCS



PART B -- FRAME B, 1 PCS




PART H -- LONG PIVOT SHAFT, 1 PCS

-		392	
			-
	0		0


PART C -- FOOT FRAME , 2 PCS




PART D -- FRAME D, 1 PCS



PART E -- FRAME E, 1 PCS



PART F -- FRAME F, 1 PCS




PART J -- SHORT PIVOT SHAFT, 1 PCS

L	308	
0		0


PART K -- CAM, 1 PCS




PART L -- FRAME L, 1 PCS



PART M -- THIGH FRAME , 2 PCS



PART G -- FRAME G, 1 PCS



PART #60 -- PLASTIC END CAP, 4 PCS . PART #67 -- POP PIN, 1 PCS Ø25mm




PART #62 -- SLEEVE, 4 PCS Ø50X145mm




PART #63 -- RUBBER BUMPER, 1 PCS Ø38mm




PART #64 -- TOP PLATE, 1 PCS



PART #65 -- SELECTOR ROD TOP BOLT , 1 PCS



PART #66 -- BACK PAD, 1 PCS





PART #68 -- THIGH PAD, 2 PCS



PART #69 -- CABLE, 1 PCS

3620mm




PART #70 -- ADJUSTMENT PLATE, 1 PCS




PART #71 -- AJDUSTMENT LEVER, 1 PCS



PART #72 -- SEAT PAD, 1 PCS



PART #87 -- BACK PAD, 7 PCS 50X50mm



PART #88 -- PLASTIC END CAP, 2 PCS 25X76mm



PART #89 -- PLASTIC END CAP, 1 PCS PART #94 -- HANDLE END CAP, 2 PCS 50X50mm



PART #90 -- BUSHING, 4 PCS Ø25XØ12.5mm



PART #91 -- BUSHING, 4 PCS Ø38XØ25mm



PART #92 -- 4.5" PULLEY, 5 PCS



PART #93 -- HANDLE RING, 2 PCS






PART #97 -- CABLE CYLINDER LOCK, 1 PCS




### PART #98 -- SELECTOR ROD, 1 PCS




PART WF -- BACK SHROUD, 1 PCS



PART WG -- TOP SHROUD, 1 PCS



PART #99 -- **SPACER**, 2 PCS Ø38mm



PART #100 -- SNAP RING, 1 PCS








# Be careful to assemble all components in the sequence they are presented.

NOTE:

Finger tighten all hardware first in this step. Wrench tighten ALL hardware at the end of STEP 1D. Some components may be pre-assembled. Nylon lock nuts will not fully screw onto bolts, they must be wrench tighten to fully go on.

- 1A. Attach Frame A (A) to Weight Stack Frame (WA) using:
  - 4 (#7) M12X35mm Hex Head Bolt
  - 8 (#53) 13mmX24mm Flat Washer
  - 4 (#42) M12 Nylon Lock Nut
- **1B.** Attach two Foot Frames **(C)** to Frame A **(A)** using:
  - 2 (#1) M10X105mm Hex Head Bolt
  - 4 (#52) 11mmX20mm Flat Washer
  - 2 (#41) M10 Nylon Lock Nut
- 1C. Attach Frames B (B) to Frame A (A) using:
  - 2 (#6) M10X80mm Hex Head Bolt
  - 4 (#52) 11mmX20mm Flat Washer
  - 2 (#41) M10 Nylon Lock Nut
- Insert Back Seat Frame (P) into Frame (B) and screw in the M8X20mm Socket Head Cap Screw (#10) at the bottom of Frame (B)

### Note: M8X20mm Socket Head Cap Screw is pre-assembled on Frame (B)



step 2


# Be careful to assemble all components in the sequence they are presented.

### NOTE:

Finger tighten all hardware first in this step. Wrench tighten ALL hardware at the end of STEP 2C. Some components may be pre-assembled. Nylon lock nuts will not fully screw onto bolts, they must be wrench tighten to fully go on.

### 2A. Insert short Shaft Pin (J) into Frame A (A) and secure it using

- 1 (#8) M10X25mm Hex Head Bolt
- 1 (#52) 11mmX20mm Flat Washer
- 2B. Insert long Shaft Pin (H) into Frame A (A) and secure it using
  1 (#8) M10X25mm Hex Head Bolt
  1 (#52) 11mmX20mm Flat Washer
- **2C.** Insert Cam (K) and Frame L (L) onto Shaft Pin (H) in the sequence presented in Step 2 Drawing using:
  - 2 (#99) 32mm Bushing Ring
  - 1 (#8) M10X25mm Hex Head Bolt
  - 1 (#100) Snap Ring
  - 1 (#82) End Cap
- Note: Please be careful when you may need to lift up Frame A to wrench tighten M10X25mm Hex Head Bolt (#8)
- 2D. Insert two Plastic End Caps (#87) onto Frame A (A).



# Be careful to assemble all components in the sequence they are presented.


#### NOTE:

Finger tighten all hardware first in this step. Wrench tighten ALL hardware at the end of STEP 3F. Some components may be pre-assembled. Nylon lock nuts will not fully screw onto bolts, they must be wrench tighten to fully go on.

- **3A.** Insert Frame G (G) onto Short Pivot Shaft (J).
- **3B.** Insert Frame F (F) onto Long Pivot Shaft (H).

Note: The Pop Pin of Frame F (F) has to be engaged in the adjustment hole of Cam (K)

- **3C.** Connect Frame G (G) to Frame F (F) using
  - 1 (R) Bracket
  - 1 (#52) 11mmX20mm Flat Washer
  - 1 (#41) M10 Nylon Lock Nut
- 3D. Attach Frame E (E) to Pivot Shafts (J & H) using
  2 (#8) M10X25mm Hex Head Bolt
  2 (#52) 11mmX20mm Flat Washer
- 3E. Attach Frame D (D) to Frame B (B) using:
  - 2 (#6) M10X80mm Hex Head Bolt
  - 4 (#52) 11mmX20mm Flat Washer
  - 2 (#41) M10 Nylon Lock Nut
- **3F.** Attach Frame D (D) to Frame E (E) using:
  - 2 (#6) M10X80mm Hex Head Bolt
  - 4 (#52) 11mmX20mm Flat Washer
  - 2 (#41) M10 Nylon Lock Nut
- **3G.** Insert two Plastic End Caps (#87) onto Frame E (E).



# Be careful to assemble all components in the sequence they are presented.


#### NOTE:

Finger tighten all hardware first in this step. Wrench tighten ALL hardware at the end of STEP 4B. Some components may be pre-assembled. Nylon lock nuts will not fully screw onto bolts, they must be wrench tighten to fully go on.

# 4A. Attach each Thigh Frame (M) on Frame G (G) & Frame F (F) using 2 - (#20) M10X25mm Flat Head Cap Screw 2 - (#77) Ø38mm End Cap

### 4B. Attach Handle Bars (Q & N) on Frame D (D) using

- 2 (#5) M10X75mm Hex Head Bolt
- 4 (#52) 11mmX20mm Flat Washer
- 2 (#41) M10 Nylon Lock Nut



step 5

# Be careful to assemble all components in the sequence they are presented.

### NOTE:

Finger tighten all hardware first in this step. Wrench tighten ALL hardware at the end of STEP 5H. Some components may be pre-assembled. Nylon lock nuts will not fully screw onto bolts, they must be wrench tighten to fully go on.


**5A.** Install Chrome Guide Rods (WD) into the holes in the Weight Stack Frame (WA).

# Note: Install the rod ends with side holes into the bottom section of the Weight Stack Frame

- 5B. Install Rubber Donuts (#80) and slide to the bottom of the Guide Rods
- **5C.** Tilt Guide Rods **(WD)** away from the Weight Stack Frame **(WA)** and install 15pcs of weight plates **(#36)**. Be careful to hold guide rods steadily when installing weight plates.

# Note: Please make sure the grooves of the weight plates are faced down during installation.

- 5D. Install Top Plate & Selector Rod Assembly (#98) onto the Guide Rods .
- **5E.** Install the Selector Rod Top Bolt (#65), the 1/2" Lock Nut (#40) and the 1/2" Spring Washer (#57).
- **5F.** Install Shaft Collars **(#85)** onto the Guide Rods so they are directly below the guide rod holes in the upper section of the Weight Stack Frame.
- **5G.** Slide Shaft Collars **(#85)** upward so they lock the guide rods into position by tightening the Set Screws **(#12)**
- **5H.** Install Weight Stack Pin (**#71**) using the key ring end through the Selector Rod Top Bolt (**#65**).




# Be careful to assemble all components in the sequence they are presented.

### NOTE:

Finger tighten all hardware first in this step. Wrench tighten ALL hardware at the end of STEP 6D. Some components may be pre-assembled. Nylon lock nuts will not fully screw onto bolts, they must be wrench tighten to fully go on.

- **6A.** Install Cable **(#69)** by first assembling the ball end into the Selector Rod Top Bolt **(#65)** and attaching the Cable Cylinder Lock **(#97)** over the ball end of the cable. Secure it by tighten in the Set Screw **(#11)**
- **6B.** Install the M10X35mm Hex Head Bolt **(#2)** through the slot hole of the Selector Rod Top Bolt **(#65)** by fastening the M10 Nylon Lock Nut **(#41)**.
- **6C.** Route Cable **(#69)** while installing five Pulleys **(#92)** into frames as shown in Step 5 Drawing using
  - 4 (#4) M10X50mm Hex Head Bolt
  - 1 (#5) M10X75mm Hex Head Bolt
  - 8 (#52) 11mmX20mm Flat Washer
  - 5 (#41) M10 Nylon Lock Nut
- **6D.** Put the end of the Cable **(#69)** through the hole of the Cam **(K)** and screw in the M4X15mm Socket head Cap Screw **(#9)**
- Note: M4X15mm Socket Head Cap Screw (#9) is pre-assembled on Cam (K).






# Be careful to assemble all components in the sequence they are presented.

### NOTE:

Wrench tighten ALL hardware at the end of Each Step. Some components may be pre-assembled. Nylon lock nuts will not fully screw onto bolts, they must be wrench tighten to fully go on.

- **7A.** Attach Short Metal Shrouds (**WB**) and Long Metal Shrouds (**WC**) to Weight Stack Frame (**WA**) using:
  - 4 (#18) M8X25mm Button Head Cap Screw
  - 8 (#55) 9mmX16mm Flat Washer
  - 4 (#44) M8 Nylon Lock Nut
- **7B.** Bend the Plastic Shrouds (WE & WF) and insert them to the side slots of the Metal Shrouds (WB & WC).
- 7C. Attach Top Shroud (WG) to Weight Stack Frame (WA) using:
  - 3 (#13) M6X16mm Phillips Head Screw
  - 3 (#54) 6.6mmX12mm Flat Washer




# Be careful to assemble all components in the sequence they are presented.


### NOTE:

Finger tighten all hardware first in this step. Wrench tighten ALL hardware at the end of STEP 8D. Some components may be pre-assembled. Nylon lock nuts will not fully screw onto bolts, they must be wrench tighten to fully go on.

- 8A. Attach Back Seat Pad (#66) to Back Seat Frame (P) using:
  - 2 (#4) M10X50mm Hex Head Bolt
  - 2 (#51) 10mm Spring Washer
  - 2 (#52) 11mmX20mm Flat Washer
- **8B.** Attach Seat Pad (#72) to Frame D (D) using:
  - 2 (#5) M10X75mm Hex Head Bolt
  - 2 (#51) 10mm Spring Washer
  - 2 (#52) 11mmX20mm Flat Washer
- 8C. Attach Thigh Pad (#68) to Thigh Frame (M) on the left using:
  - 2 (#3) M10x45mm Hex Head Bolt
  - 2 (#51) 10mm Spring Washer
  - 2 (#52) 11mmX20mm Flat Washer
- 8D. Attach Thigh Pad (#68) to Thigh Frame (M) on the right using:
  - 1 (#3) M10x45mm Hex Head Bolt
  - 1 (#16) M10x50mm Button Head Cap Screw
  - 1 (#51) 10mm Spring Washer
  - 1 (#52) 11mmX20mm Flat Washer
  - 1 (#63) Rubber Bumper







Body-Solid Built for Life

# S2IOT

### PLEASE WRITE YOUR SERIAL NUMBER IN THE BOXES BELOW

### 

1900 S. Des Plaines Ave. Forest Park, Il 60130 Phone:(708)427-3555 Fax:(708)427-3556 Hours: M-F 8:30 - 5:00 CST

www.bodysolid.com

Copyright 2009. Body-Solid. All rights reserved. Body-Solid reserves the right to change design and specifications when we feel it will improve the product. Body-Solid machines maintain several patented and patent pending features and designs. All rights reserved on all design patents and utility patents.